

HELMET ASSEMBLY

22036	HELMET SHELL	29037	BALL LEVER ASSEMBLY
21135	NECK RING (FEMALE)	21139	PIVOT
29199	FRONT DOOR ASSEMBLY	21161	BALL LEVER
21116A	FRONT DOOR BASE	23032	WASHER
21117	FRONT DOOR	23058	PIVOT PIN
21118	FRONT WINDOW RETAINING RING	29040	EXHAUST VALVE ASSEMBLY
21119	FRONT DOOR GUARD	21128	EXHAUST BODY (BANANA)
21120	FRONT DOOR WING NUT	21129	EXHAUST BODY WASHER
23028	FT DOOR TOGGLE BOLT PIN	23084	BONNET
23029	FRONT DOOR HINGE PIN	21184	HANDLE
23030	FT DOOR TOGGLE BOLT WASHER	22039	YOKE
23138	FRONT DOOR TOGGLE BOLT	24027	SCREWS 8-32 x 3/8"RH (2 - YOKE)
26009	FRONT DOOR GASKET	27092	PRIMARY SPRING
27042	FRONT DOOR LIGHT	27091	SECONDARY SPRING
27064	HINGE PIN COTTER PIN	23085	BEARING PIECE
21114	SIDE WINDOW GUARD	23086	SPRING RETAINER
21115A	SIDE WINDOW BASE	23087	STOP PIN (2)
27041	SIDE WINDOW LIGHT	29086	OUTLET VALVE ASSEMBLY
21121	TOP WINDOW BASE	23080	CHIN BUTTON
21122	TOP WINDOW GUARD	23081	EXHAUST VALVE STEM
27040	TOP WINDOW LIGHT	23082	ADJUSTING SLEEVE
24027	SCREWS 8-32 x 3/8"RH (16 - GUARD)	23083	LOCK SCREW
21162	WELDING LENS BRACKET	29039	NON-RETURN VALVE
21059	AIR / COMM ELBOW WASHER	23060	NON-RETURN BODY
21147	AIR INLET ELBOW	29039C	CHECK VALVE
21146	COMMUNICATIONS ELBOW	59523	O-RING (CHECK VALVE)
23120	COMM ELBOW GLAND NUT	23077	RETAINING PLUG
23121	COMM ELBOW GLAND RING	27059	LEATHER GASKET
23122	COMM ELBOW BUSHING	23059	AIR CLOSE CAP
27058	3/16" x 1/2" COPPER RIVETS (6)	27056	AIR CLOSE CAP WASHER
21150	TELEPHONE CUP	29035	SPITCOCK VALVE ASSEMBLY
24028	TRANSCEIVER STUDS (2)	21124	SPITCOCK BODY
22037	TRANSCEIVER STUD SPACER	21125	SPITCOCK BODY WASHER
24029	TRANSCEIVER STUD NUTS (4)	21123	SPITCOCK STEM
21270	TRANSCEIVER BRACKET	21126	SPITCOCK STEM WASHER
21271	TRANSCEIVER	24015	SPITCOCK STEM NUT
21272	RUBBER GROMMET	24017	STOP SCREW
22038	PHONE WIRE TABS (3)	29102	BREASTPLATE ASSEMBLY
27185	24" 2 WIRE COMM CABLE	22017	SHELL
21101	COMM CLOSE CAP	21130	BOTTOM COLLAR STRAP
27057	COMM CLOSE CAP WASHER	27080	WIRE BEAD
23300	COMM CONTACT ASS'Y	21136	NECK RING (MALE)
23301	SLEEVE	21149	BREASTPLATE LOOPS
23302	SPACER	21125A	LOOP WASHER
23303	WASHER	23033	SHORT STUDS (11)
23304	PLUG GUIDE	23034	LONG STUD
23305	CONTACT HOLDER	21141	BRAIL LR
23306	CONTACT HOUSING	21142	BRAIL LF
23307	CONTACT SPRING	21143	BRAIL RF
23308	CONTACT COVER	21144	BRAIL RR
23309	CONTACT SPACER	21127	WINGNUT
23310	6-32 x 1 1/4" FHMS BRASS	21134	FLANGED WINGNUT
22027	AIR DUCT, RIGHT	22033	BREASTPLATE STUD WASHER
22028	AIR DUCT, FRONT	27025	NECK RING GASKET
22029	AIR DUCT, LEFT	27061	NAMEPLATE
22030	AIR DUCT, INLET	27052	1/8" COPPER RIVETS (2)

22024	LATCH
27052	LATCH PIVOT PIN
23137	LOCKSTOP
29054	SAFETY CHAIN ASSEMBLY
27053	CHAIN LOOP
27054	FLAT CHAIN
27054B	BEAD CHAIN ASSEMBLY
27055	LOCK PIN
27204	WELDING LENS ASSEMBLY
	TIN PLATING